



















# Instruction Sheet











**Subject: Adding Taco Bell Cheddar Chalupa**

**Models affected: Taco Bell FilterQuick Touch Fryers**

Follow these instructions to add Cheddar Chalupa.

DISPLAY	ACTION
	1. Press the Home button.
 <b>RECIPES</b>	2. Press the Recipes button.
<b>1 6 5 0</b>	3. Enter <b>1 6 5 0</b>
	4. Press the √ (check) button.
	5. Press the green + button.
	6. Using the keyboard, enter <b>CHEDDAR</b> . 7. Press the space bar. 8. Using the keyboard, enter <b>CHALUPA</b> .
	9. Press the √ (check) button.
 	10. Press the Temperature button.

DISPLAY	ACTION
	<p>11. Use the keypad to enter <b>3 5 0</b>.</p>
	<p>12. Press the ✓ (check) button.</p>
	<p>13. Press the cook time button.</p>
	<p>14. Use the keypad to enter <b>5 0</b>.</p>
	<p>15. Press the ✓ (check) button.</p>
	<p>16. Ensure cook time is set to <b>:50</b>.</p>
	<p>17. Press the down arrow five (5) times.</p>
 	<p>18. Press the Filter button.</p>
	<p>19. Press the OFF button.</p>

DISPLAY	ACTION
 	20. Press the ✓ (check) button.
	21. Press the icon to link with this product.
	22. Press the ✓ (check) button.
	23. Press the LUNCH and CHANGEOVER buttons.
	24. Press the ✓ (check) button.
	25. The controller displays SAVED.
	26. Press the ✓ (check) button.
	27. Press the home button.
 <b>CREW MODE</b>	28. Press the Crew Mode button to return to main screen.