


















# Instruction Sheet

**Subject: Edit Taco Bell Chalupa Cook Time**

**Models affected: Taco Bell FilterQuick Touch Fryers**

Follow these instructions to edit Chalupa cook time.

DISPLAY	ACTION
	1. Press the Home button.
 <b>RECIPES</b> <b>1 6 5 0</b>	2. Press the Recipes button.
	4. Press the ✓ (check) button.
	5. Press the Chalupa icon. The border should change from gray to green.
	6. Press the pencil icon at the bottom of the screen to edit an existing product.
	7. Chalupa is displayed.
	8. Press the ✓ (check) button.
	9. Chalupa parameters are displayed.

DISPLAY	ACTION
	10. Press the cook time button.
	11. Use the keypad to enter <b>50</b> .
	12. Press the ✓ (check) button.
	13. Ensure cook time is set to <b>:50</b> .
	14. Press the back-arrow button.
	15. The controller displays <b>SAVED</b> .
	16. Press the ✓ (check) button.
	17. Press the home button.
 <b>CREW MODE</b>	18. Press the Crew Mode button to return to main screen.